

Think Automation and beyond...

# Flameproof and Increased Safety EC2B Control Boxes



### Complies with IECEx, ATEX, Ex-CCC, UL/c-UL and TIIS. Ideal for use in factories.

- Corrosion resistant stainless steel enclosure.
- Applicable in areas where explosive gases/steam exist including hydrogen and acetylene, and environments subject to dust (ATEX, IECEx, Ex-CCC).
- Available with a variety of switches/pilot lights and enclosures
- Available for global applications

Global: IECEx

North America: UL/c-UL Europe: CE/ATEX China: Ex-CCC Japan: TIIS

• Degree of protection: IP65 (IEC 60529), Type4X (UL)

















### **Specifications**

Degree of protection	IP65 (IEC60529), Type 4X (UL)
Housing Material	Stainless steel (SUS304)
Standard Coating *	5Y7/1 (semi gloss) melamine baking (coating thickness: 10 µm) 1-column: Outside coating 2-, 3-, 4-column: Inside and outside coating
Rated Insulation Voltage	600V (with pilot light or ET2A-8PE screw terminal block: 500V) Meter AC input: 300V Meter DC input: 150V
Insulation Resistance	100 MΩ minimum (500V DC megger)
Operating Temperature	-20 to +50°C (no freezing)
Operating Humidity	45 to 85% (no condensation)
Altitude	2000m maximum

- \* Special coating, buffing (#400), and special color are possible.
- \* Contact IDEC for details.

# Explosion protection specifications and certification number

Certification	Explosion Protection	Certification No.		
TIIS	Ex de IIC T6	See Page 24		
IECEx	Ex db eb IIC T6 Gb Ex tb IIIC T80°C Db (dust)	IECEx PTB 15.0032		
ATEX	Ex db eb IIC T6 Gb Ex tb IIIC T80°C Db (dust)	PTB 08 ATEX 1048		
UL	Class I, Zone 1 AEx d e IIC T6 Gb	E347230		
OL	Class I Div 2, Groups A, B, C and D			
c-UL	Class I, Zone 1, Ex de IIC T6 Gb			
Without pilot light	Class I Div 2, Groups A, B, C and D			
c-UL	Class I, Zone 1, Ex de IIB T6 Gb			
With pilot light	Class I, Div 2, Groups C and D			
Ex-CCC	Ex de IIC T6 Gb	202001230434		
	Ex tD A21 IP65 T80°C (dust)	8115		

### IECEx/ATEX/Ex-CCC, UL/c-UL/ IECEx/ATEx, and TIIS Comparison


	IECEx/ATEX/Ex-CCC certified		UL/c-UL, IECEx/ATEX certified	TIIS certified
Part No.		EC2B	EC2B-U	EC2B-
Applicable Enclosure		All enclosures	All enclosures except for 6 Control Units x 4 Column	All enclosures
Mounting Style		Wall Mount	Wall Mount	Wall Mount Pole Mount
+	Pilot Light	Yes	Yes (*1)	Yes
Control Unit	Pushbutton	Yes (*2)	Yes (*2)	Yes
trol	Emergency Pushbutton	Yes	Yes	Yes
Son	Selector Switch	Yes	Yes	Yes
ole (	Key Selector Switch	Yes	Yes	Yes
Applicable	Meter Yes		Yes	Yes (*3)
\pp	Buzzer	_	_	Yes
1	Variable Resistor	_	_	Yes
Reducer Screw		Metric Thread (standard)	NPT Thread (standard)	Pipe Parallel Thread (standard)
		NPT Thread/Pipe Parallel Thread	Metric Thread	Metric Thread/NPT Thread
Cable	Lead-in Fitting	<b>—</b> (*4)	<b>-</b> (*4)	Yes (HPN)
Lead-	in Port Plug	<b>—</b> (*4)	<b>-</b> (*4)	Yes (GBE)
Degre	e of Protection	IP65	IP65, TYPE4X (UL)	IP65
Grounding Terminal Screw Material		Stainless Steel	Stainless Steel	Brass
plq	Stranded Wire (mm²) 1.25 to 2.5		1.5 to 2.5	1.25 to 2.5
Applicable Wire	Solid Wire (mm²) 1.2 to 1.6		1.2 to 1.6	1.2 to 1.6
Ар	Solid/Stranded Wire (AWG)	16-14	16-14	16-14

- \*1: c-UL explosion protection is different when pilot light is installed.
- \*2: Part no. is different from TIIS certified model.
- \*3: Part no. of TIIS certified meter is different from the meter certified by other organizations.
- \*4: Use fittings and plugs commercially available compliant to the corresponding standards.

# Control Boxes (TIIS, IECEx, ATEX, Ex-CCC, UL/c-UL)

# **Control Box**

	1, 2 contr	ol units	3 control units	4 control units	5 control units
1-column				0000	
2-column	0.0		0000		000000
3-column		000	0000	00000	000000



### **Control Units**

Control Unit	Pilot Light		Emergency Stop Switch		
Shape	Round	Flush	Extended	Mushroom	Mushroom (ø40)
Operation	ı		Momentary		Push-to-lock, pull or turn-to-reset
Shape					1
Illumination color/but- ton color	R (red) G (green) Y (yellow) A (amber)  W (white) S (blue) PW (pure white)	B (black) G (gree	on) R (red) W (white)	Y (yellow) S (blue)	R (red)
Part No.	EU2B-YL	EU2B-YB1	EU2B-YB2	EU2B-YB3	EU2B-YBV
Page	15		15		15

Control Unit	Selecto	r Switch	Buzzer (*)	Variable Reducer (*)	Meter
	Knob Operator	Key			
Shape		Top of		(6)	
Part No.	EU2B-YS	EU2B-YSK	EC9F-Z	EC9E-R	EU2B-YM/EC9F-M
Page	1	6	16	17	17

<sup>\*</sup> Only approved under TIIS standards.

# Nameplate/Mounting Hole Plug


Name	Control Unit Nameplate	Marking Plates for Control Unit Nameplates	Emergency Stop Switch Nameplate Sticker	Control Unit Mounting Hole Plug
Shape		MAND OFF AUTO START ON STOP	000	
Part No.	EU9Z-NM	EU9Z-NP	EU9Z-NVS	EU9Z-BP
Page	23	23	23	23

<sup>\*</sup> See page 21 for accessories.

### Standard Part No. Development (reference)

The chart below describes the configuration of standard model. See next page for standard model.

For custom order models, contact IDEC for part number, prices, and delivery time. Please use this chart for interpreting part numbers, not for developing part numbers.



#### Standard control box

- Specify the Part No. when ordering standard control boxes.
- For control unit specifications and part numbers, see pages 13 to 17. For cable lead-in fitting specifications, see page 9. For specifications of control unit nameplate and emergency stop switch nameplate sticker, see page 23.
- If a control unit nameplate or emergency stop switch nameplate sticker is not required on standard control boxes, add "0" after the Part No.

Example: EC2B-1102BF2NC10

#### Custom assembled control box

- If the required control units, accessories, and cable lead-in fittings are not standard specifications, and if control box nameplate (NP) is required, specify the required specifications on the Specification Sheet on pages 29 to 30.
- TIIS certified models: the model and number of control units that can be installed depend on the size of control box. See page 24 for TIIS certified products and specify the control unit configuration.

#### Standard and custom assembled control boxes

• Part No. is shown on control boxes as below.

#### TIIS certified

TIIS certified part no. (see page 24.)

Part No. Example

Wall mount Part No:

EC2B-1102BF2NF2

Part No. on control box: EC2B-1102-F

### IECx/ATEX/Ex-CCC certified

EC2B-□□□□-GL

Part No. Example

Part No: EC2B-1102BM3NC3-GL

Part No. on control box: EC2B-1102-GL

#### UL/c-UL, IECEx/ATEX certified

EC2B-□□□□-U

Part No. Example

Part No: EC2B-1102BN2F4-U Part No. on control box: EC2B-1102-U

• See below for the symbols of control units.

(P): Pilot light

(B): Pushbutton

🗐 : Emergency stop switch

Selector switch/Key selector switch

SS: Selector

BZ: Buzzer

(R): Variable Resistor

(B): Control Unit Mounting Hole Plug

# **Control Boxes**

### 1 Control Unit × 1 Column (without wiring) (standard models)

### **Pushbuttons**

Shape/Symbol Mounted Control Units					
		Flush momentary 1NO contact Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NC contact Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact Nameplate OFF Button color (supplied with black, green, red, and white buttons)
Part No. (IECEx/ATEX/Ex-CCC certified)		EC2B-1102BM3N□1-GL	EC2B-1102BM3N□2-GL	EC2B-1102BM3N□3-GL	EC2B-1102BM3N□4-GL
Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-1102BN2N□1-U	EC2B-1102BN2N□2-U	EC2B-1102BN2N□3-U	EC2B-1102BN2N□4-U
Part No. (TIIS certified)		EC2B-1102BF2N□1	EC2B-1102BF2N□2	EC2B-1102BF2N□3	EC2B-1102BF2N□4
TIIS Type Test	C termi- nal style	1 10:19254	TC19254	TC19254	TC19254
Approval No. (*)	F termi- nal style	TC19255	TC19255	TC19255	TC19255

**Pilot Lights** 

i liot Lights							
Shape/Symbol Mounted Control Units							
x1 X2 ⊕			200/220V AC Illumination color: red	24V AC/DC Illumination color: red	100/110V AC Illumination color: green	200/220V AC Illumination color: green	24V AC/DC Illumination color: green
Part No. (IECEx/ATEX/Ex-0 certified)	CCC	EC2B- 1101BM3N□1-GL	EC2B- 1101BM3N□2-GL	EC2B- 1101BM3N□3-GL	EC2B- 1101BM3N□4-GL	EC2B- 1101BM3N□5-GL	EC2B- 1101BM3N□6-GL
Part No. (UL/c-UL, IECEX/certified)	ATEX	EC2B- 1101BN2N□1-U	EC2B- 1101BN2N□2-U	EC2B- 1101BN2N□3-U	EC2B- 1101BN2N□4-U	EC2B- 1101BN2N□5-U	EC2B- 1101BN2N□6-U
Part No. (TIIS certified)		EC2B- 1101BF2N□1	EC2B- 1101BF2N□2	EC2B- 1101BF2N□3	EC2B- 1101BF2N□4	EC2B- 1101BF2N□5	EC2B- 1101BF2N□6
TIIS Type Test	C termi- nal style	TC19254	TC19254	TC19254	TC19254	TC19254	TC19254
Approval No. (*)	F termi- nal style	TC19255	TC19255	TC19255	TC19255	TC19255	TC19255

### **Emergency Stop Switches**

Shape/Sym	nbol		Mounted Control Units
	1 0	1	Emergency stop switch 2NC contact Nameplate EMERGENCY STOP Button color (red)
Part No. (IECEx/ATEX/Ex-CCC certified)			EC2B-1102BM3N□7-GL
Part No. (UL/c-UL, IECEX/ATEX certified)			EC2B-1102BN2N□7-U
Part No. (TIIS certified)			EC2B-1102BF2N□7
TIIS Type Test Approval No. (*)  C terminal style F terminal style			TC19254
			TC19255

- Specify terminal style code in place of in part no. C (standard screw terminal), F (finger-safe screw terminal)
- Contact IDEC for custom assembled control boxes.
- \* C terminal style (exposed screw terminal) and F terminal style (finger-safe screw terminal) have different TIIS certification numbers.

# 1 Control Unit × 1 Column (without wiring) (standard models)

#### **Selector Switches**

<del>Colociol Cilli</del>	Science Switches				
Shape/Sy	/mbol		Mounted Control Units		
off of	1 3	1	Knob selector 2-position maintained 1NO-1NC contact Name plate OFF-ON		
Part No. (IECEx/ATEX/Ex-CCC certified)			EC2B-1106BM3N□1-GL		
Part No. (UL/c-UL, IECEX/ATEX certified)			EC2B-1106BN2N□1-U		
Part No. (TIIS certified)			EC2B-1106BF2N□1		
TIIS Type Test	C terminal style		TC19256		
Approval No. (*)	F terminal style		TC19257		

### **Key Selector Switches**

Shape/Sy	ymbol		Mounted Control Units	
OFFO P		D	Key selector 2-position maintained (removable at all positions) 1NO-1NC contact Nameplate OFF-ON	
Part No. (IECEx/ATEX/Ex-	CCC certifie	d)	EC2B-1106BM3N□4-GL	
Part No. (UL/c-UL, IECE certified)	X/ATEX		EC2B-1106BN2N□4-U	
Part No. (TIIS c	ertified)		EC2B-1106BF2N□4	
TIIS Type Test C terminal style		ı	TC19256	
Approval No. (*)	F terminal style		TC19257	

### 2 Control Units × 1 Column (without wiring) (standard models)

#### Two Flush Pushbuttons

I WO FIUSII PUSIIDULIOIIS					
Shape/Symbol			Mounted Control Units		
			Flush momentary 1NO contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)		
	2	2	Flush momentary 1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)		
Part No. (IECEx/ATEX/Ex-C	Part No. (IECEx/ATEX/Ex-CCC certified)		EC2B-2102BM3N□1-GL		
Part No. (UL/c-UL, IECEX certified)	(UL/c-UL, IECEX/ATEX		EC2B-2102BN2N□1-U		
Part No. (TIIS ce	ertifie	d)	EC2B-2102BF2N□1		
TIIS Type Test	C terminal style		TC19254		
Approval No. (*)	F terminal style		TC19255		

### **Two Mushroom Pushbuttons**

Shape/Symbol			Mounted Control Units
[3] 1 	(I)	①	Mushroom momentary 1NO-1NC contact, Nameplate ON Button color (black)
3  1	2	2	Mushroom momentary 1NO-1NC contact, Nameplate OFF Button color (red)
Part No. (IECEx/ATEX/Ex-C0	CC ce	rtified)	EC2B-2102BM3N□4-GL
Part No. (UL/c-UL, IECEX, certified)	/ATE>	<b>~</b>	EC2B-2102BN2N□4-U
Part No. (TIIS cer	Part No. (TIIS certified)		EC2B-2102BF2N□4
TIIS Type Test	C terminal style		TC19254
Approval No. (*)			TC19255

### Combination Pilot Lights/Pushbuttons

Shape/Symbol			Mounted Control Units			
V1		1	100/110V AC Illumination color: red	200/220V AC Illumination color: red	24V AC/DC Illumination color: red	
3	X2 ① 1 1 2 2	2	Flush momentary 1NO-1NC contact Name plate STOP Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact Name plate STOP Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact Name plate STOP Button color (supplied with black, green, red, and white buttons)	
Part No. (IECEx/ATEX/Ex-	CCC certif	ied)	EC2B-2110BM3N□1-GL	EC2B-2110BM3N□2-GL	EC2B-2110BM3N□3-GL	
Part No. (UL/c-UL, IECEX/ATEX c	Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-2110BN2N□1-U	EC2B-2110BN2N□2-U	EC2B-2110BN2N□3-U	
Part No. (TIIS certified)	Part No. (TIIS certified)		EC2B-2110BF2N□1	EC2B-2110BF2N□2	EC2B-2110BF2N□3	
TIIS Type Test	C terminal style		TC19254	TC19254	TC19254	
Approval No. (*)	F termir style	nal	TC19255	TC19255	TC19255	

- Specify terminal style code in place of in part no. C (standard screw terminal), F (finger-safe screw terminal)
- Contact IDEC for custom assembled control boxes.
- \* C terminal style (exposed screw terminal) and F terminal style (finger-safe screw terminal) have different TIIS certification numbers.

### 2 Control Units × 1 Column (without wiring) (standard models)

Combination Pilot Light/Selector Switch

Shape/Symbol			Mounted Control Units				
	$X1 \otimes X2 \otimes X2 \otimes X1 \otimes X2 \otimes X1 \otimes X1 \otimes X1 \otimes $	1)	100/110V AC Illumination color: red	200/220V AC Illumination color: red			
OFF ON	2 4	2	Knob, 2-position, 1NO-1NC contact Maintained, Name plate OFF-ON	Knob, 2-position, 1NO-1NC contact Maintained, Name plate OFF-ON			
Part No. (IECEx/ATEX/Ex-C	Part No. (IECEx/ATEX/Ex-CCC certified)		EC2B-2117BM3N□1-GL	EC2B-2117BM3N□2-GL			
Part No. (UL/c-UL, IECEX/A	Part No. (UL/c-UL, IECEX/ATEX certifie		EC2B-2117BN2N□1-U	EC2B-2117BN2N□2-U			
Part No. (TIIS certi	Part No. (TIIS certified)		EC2B-2117BF2N□1	EC2B-2117BF2N□2			
TIIS Type Test C termina style		al	TC19258	TC19258			
Approval No. (*)	F termina style	al	TC19259	TC19259			

### 3 Control Units × 1 Column (without wiring) (standard models)

Combination 1 pilot light/2 pushbuttons

Shape/Syr	mbol		Mounted Control Units				
[ <del>V</del> ]	<u>X1</u> <u>X2</u>	1	100/110V AC Illumination color: red	200/220V AC Illumination color: red	24V AC/DC Illumination color: red		
	1 (1)	2	Flush momentary 1NO contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)		
	2   (2   1   (2	3	Flush momentary 1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)		
Part No. (IECEx/ATEX/Ex-C	CC cert	tified)	EC2B-3110BM3N□1-GL	EC2B-3110BM3N□2-GL	EC2B-3110BM3N□3-GL		
Part No. (UL/c-U ATEX certified)	Part No. (UL/c-UL, IECEX/ ATEX certified)		EC2B-3110BN2N□1-U	EC2B-3110BN2N□2-U	EC2B-3110BN2N□3-U		
Part No. (TIIS ce	Part No. (TIIS certified)		EC2B-3110BF2N□1	EC2B-3110BF2N□2	EC2B-3110BF2N□3		
TIIS Type Test	C terr		TC19260	TC19260	TC19260		
Approval No. (*)	F tern style	ninal	TC19261	TC19261	TC19261		

### 3 Pushbuttons

Shape/Syr	nbol		Mounted Control Units
3	1 7 2	1	Flush momentary
3	1   7  @ 2	2	1NO-1NC contact, Blank nameplate Button color (supplied with black,
3	1 3	3	green, red, and white buttons)
Part No. (IECEx/ATEX/Ex-C	CC cei	rtified)	EC2B-3102BM3N□1-GL
Part No.(UL/c-UL, IECEX/ ATEX certified)			EC2B-3102BN2N□1-U
Part No. (TIIS cer	rtified)		EC2B-3102BF2N□1
TIIS Type Test	C terminal style		TC19260
Approval No. (*)	F terminal style		TC19261

### 1 Meter/2 Pushbuttons

Shape/Symbol		Mounted Control Units
Q	D	Specify input, capacity, and scale
3  1  2  2  2	2)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)
3  1  3  3  3  3  3  3  3  3  3  3  3  3	3)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)
Part No. (IECEx/ATEX/Ex-CCC certifie	ed)	EC2B-3152BM3N□1△-GL
Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-3152BN2N□1△-U

- Specify the meter's capacity and scale in place of △ in the part no. See page 17 for details. Contact IDEC for custom assembled control boxes.
- TIIS certified control box equipped with a meter is available with combination of other than 1 unit/1 column, 2 units/1 column, and 3 units/1 column.
- Specify terminal style code in place of in part no. C (standard screw terminal), F (finger-safe screw terminal)
- Contact IDEC for custom assembled control boxes.
- \* C terminal style (exposed screw terminal) and F terminal style (finger-safe screw terminal) have different TIIS certification numbers.

# 4 Control Units × 1 Column (without wiring) (standard models)

2 pilot lights/2 pushbuttons

Shape/Syr	Shape/Symbol			Mounted Control Units					
			100/110V AC, Illumination color: red	200/220V AC, Illumination color: red	24V AC/DC, Illumination color: red				
		2	100/110V AC, Illumination color: green	200/220V AC, Illumination color: green	24V AC/DC, Illumination color: green				
3	[1   	1 X2 2 3 4 1 2 3 4 1 2 1	3  1   	3  1   	<b>1</b>      3    3	3	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)
3	[1   7   ⊕  2	4	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)				
Part No. (IECEx/ATEX/Ex-CCC certified)		fied)	EC2B-4110BM4N□1-GL	EC2B-4110BM4N□2-GL	EC2B-4110BM4N□3-GL				
Part No. (UL/c-UL, IECEX/ATEX certified)		d)	EC2B-4110BN3N□1-U	EC2B-4110BN3N□2-U	EC2B-4110BN3N□3-U				
Part No. (TIIS certified)			EC2B-4110BF3N□1	EC2B-4110BF3N□2	EC2B-4110BF3N□3				
	C/F term nal style		TC19262	TC19262	TC19262				

1 pilot light/2 pushbuttons/1 selector switch

Shape/Symbol			Mounted Control Units	
		100/110V AC, Illumination color: red	100/110V AC, Illumination color: red 200/220V AC, Illumination color: red	
$\begin{array}{c c} X1 \otimes X2 & 0 \\ \hline 3 1 & \\ \hline & 4 2 & 0 \end{array}$	٦	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)
3  1   3   1   4   2   2   2   2   2   2   2   2   2	3	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)
1 3	4	Knob, 2-position, maintained HAND AUTO 1NO-1NC contact, Nameplate HAND-AUTO	Knob, 2-position, maintained 1NO-1NC contact, Nameplate HAND-AUTO	Knob, 2-position, maintained HAND AUTO 1NO-1NC contact, Nameplate HAND-AUTO
Part No. (IECEx/ATEX/Ex-CCC certified)		EC2B-4113BM4N□1-GL	EC2B-4113B□4N□2-GL	EC2B-4113B□4N□3-GL
Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-4113BN3N□1-U	EC2B-4113BN3N□2-U	EC2B-4113BN3N□3-U
Part No. (TIIS certified)		EC2B-4113BF3N□1	EC2B-4113BF3N□2	EC2B-4113BF3N□3
TIIS Type Test C/F terminal Approval No. (*)		TC19262	TC19262	TC19262

## 5 Control Units × 1 Column (without wiring) (standard models)

2 pilot lights/2 pushbuttons/1 selector switch

Shape/Symbol		Mounted Control Units			
F	1	100/110V AC, Illumination color: red	200/220V AC, Illumination color: red	24V AC/DC, Illumination color: red	
<u>X1</u> <u>X2</u> ①	2	100/110V AC, Illumination color: green	100/110V AC, Illumination color: green	24V AC/DC, Illumination color: green	
$\begin{array}{c c} X1 \otimes X2 \\ \hline 3 & 1 \\ \hline & 4 & 2 \\ \end{array}$	3	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate ON Button color (supplied with black, green, red, and white buttons)	
3  1 	4	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	Flush momentary 1NO-1NC contact, Nameplate OFF Button color (supplied with black, green, red, and white buttons)	
OFF ON	(5)	Knob, 2-position, Main- tained, 1NO-1NC contact, Name plate HAND-AUTO	Knob, 2-position, Maintained, 1NO-1NC contact Name plate HAND-AUTO	Knob, 2-position, Main- tained, 1NO-1NC contact Name plate HAND-AUTO	
Part No. (IECEx/ATEX/Ex-CCC certif	ied)	EC2B-5113BM4N□1-GL	EC2B-5113BM4N□2-GL	EC2B-5113BM4N□3-GL	
Part No. (UL/c-UL, IECEX/ATEX certified)		EC2B-5113BN3N□1-U	EC2B-5113BN3N□2-U	EC2B-5113BN3N□3-U	
Part No. (TIIS certified)		EC2B-5113BF3N□1	EC2B-5113BF3N□2	EC2B-5113BF3N□3	
TIIS Type Test C/F term Approval No. (*)	inal	TC19262	TC19262	TC19262	

- Specify terminal style code in place of in part no. C (standard screw terminal), F (finger-safe screw terminal)
- Contact IDEC for custom assembled control boxes.
   C terminal style (exposed screw terminal) and F terminal style (finger-safe screw terminal) have different TIIS certification numbers.

### Cable Lead-in Fittings

#### Wall Mount Reducers

Reducers installed at the bottom of the control box are as follows:

1 column: 1 reducer 2 columns: 2 reducers 3 columns: 3 reducers 4 columns: 4 reducers Material: brass (nickel-plated)



#### The following optional reducers can also be installed.

				Ap	prova	al
Control Box Style	Part No.	Thread Size	Sym- bol	IECEX ATEX Ex-CCC	UL c-UL	TIIS
	EC9E-H31 *1	G1/2 (16)	F1	0		0
<u> </u>	EC9E-H32 *1	G3/4 (22)	F2	0		•
1 column	EC9E-H33 *1	G1 (28)	F3	0		0
(1 to 3	EC9E-H3M16 *2	M16	M1	0	0	0
units)	EC9E-H3M20 *2	M20	M2	0	0	0
2, 3 col-	EC9E-H3M25 *2	M25	МЗ	•	0	0
umns	EC9E-H3M32 *2	M32	M4	0	0	0
(2, 3 control units)	EC9E-H3NPT1 *2	NPT 1/2	N1	0	0	0
tioi units)	EC9E-H3NPT2 *2	NPT 3/4	N2	0	•	0
	EC9E-H3NPT3 *2	NPT 1	N3	0	0	0
	EC9E-H42 *1	G3/4 (22)	F2	0	_	0
	EC9E-H43 *1	G1 (28)	F3	0	_	•
1, 2, 3 columns	EC9E-H44 *1	G1 1/4 (36)	F4	0	ı	0
(4, 5 control units) 3, 4 columns (6 control	EC9E-H4M25 *2	M25	М3	0	0	0
	EC9E-H4M32 *2	M32	M4	•	0	0
	EC9E-H4M40 *2	M40	M5	0	0	0
	EC9E-H4NPT2 *2	NPT 3/4	N2	0	0	0
units)	EC9E-H4NPT3 *2	NPT 1	N3	0	•	0
	EC9E-H4NPT4 *2	NPT 1 1/4	N4	0	0	0

#### : Standard reducer

O: Except for standard reducer

E: IECEx, ATEX, Ex-CCC
Blank: TIIS certified

\*2 E-UL: IECx/ATEX, UL/c-UL certified Blank: TIIS certified

• The value in ( ) is the nominal designation of the applicable metal conduit (JIS C 8305)

# Pole Mount (for TIIS certified model only)

### Packing Type Cable Lead-in Fitting

Only one cable can be lead in.

Three different packings are available for 1-, 2-, and 3-column.

Material: Brass (nickel-plated)

Box Style	Part No.	Packing	Cable Diameter D (mm)	Symbol	
		R12	ø8 ≤ D ≤ ø12		
1 column	EC9E-S10	R16	ø12 < D ≤ ø16		
		R20	ø16 < D ≤ ø20		
0.0		R18	$\emptyset 14 \le D \le \emptyset 18$	SF	
2, 3 column	EC9E-S20	R22	ø18 < D ≤ ø22		
		R26	ø22 < D ≤ ø26		

# Flameproof Packing Type Cable Lead-in Fittings (for TIIS certified model only)


Used to lead in rubber and plastic cables.

Material: Brass (nickel-plated)



Flameproof packing	Applicable cable diameter		Dimensions (mm)			
type cable lead-in fitting	D (mm)	Symbol	А	В	L	
HPN21 R8	$\emptyset 6 \le D \le \emptyset 8$	H1		04/0	07.1-	
HPN21 R10	ø8 < D ≤ ø10	H2	36	G1/2 (16)	67 to 70.5	
HPN21 R12	ø10 < D ≤ ø12	H3		(10)	70.5	
HPN22 R14	ø12 < D ≤ ø14	H4	40	G3/4	67 to	
HPN22 R16	ø14 < D ≤ ø16	H5	40	(22)	70.5	
HPN33 R18	ø16 < D ≤ ø18	H6	50	C1 (00)	77.5 to	
HPN33 R20	ø18 < D ≤ ø20	H7	50	G1 (28)	81	
HPN44 R23	ø20 < D ≤ ø23	HA	58	G1 1/4	80.5 to	
HPN44 R26	ø23 < D ≤ ø26	НВ	56	(36)	84	

- HPN44 cannot be used for 1, 2, or 3 control units/1 column.
- The dimension of B in () is the nominal designation of the applicable metal conduit. (JIS C 8305)
- When ordering TIIS certified model, specify the part no. of flameproof packing type cable lead-in fitting.



\* For IECEx/ATEX/Ex-CCC, UL/c-UL certified control boxes, use cable lead-in fittings that are commercially available.

### **Terminal Blocks**

A terminal block is not supplied with the standard control boxes (without wiring). When wiring inside the control box is required, specify the wiring circuit.

The terminal block type used on the control boxes with wiring depends on the terminal style of the control unit.


#### C terminal style (exposed screw terminal)

[Applicable terminal block]

Screw terminal: ET2A-8PE (material: polyamide)

Certification numbers:

IECEx TUR 15.0043U TÜV 15 ATEX 7799U



All dimensions in mm


### F terminal style (finger-safe screw terminal)

[Applicable terminal block]


IP20 clamp terminal: 264-238 (WAGO) (material: polyamide)


Certification numbers:

IECEX PTB 04.0003U PTB 98 ATEX 3129U



The number of terminal blocks, poles, and the installation direction that can be installed on the control box are as follows:







### **Dimensions**

### 1, 2 Control Units × 1 Column


\* Pole mount: TIIS certified model only





### 3 Control Units × 1 Column




### 4, 5 Control Units × 1 Column











### 2, 3, 4, 5 control units × 3 Columns



### 6 control units × 3 columns

# 

### 6 control units × 4 columns



# **Control Units**

**Applicable Standards** 

Applicable	Stariuarus			
Control Units	Applicable Standards	Mark	Certification No.	
	GB 12476.1 GB 12476.5 GB 3836.1 GB 3836.2 GB 3836.3	((()	2021012304363041 2021012304363046 2021012309370228 2021012313363039	
	EN60947-5-1	( €	EU Low Voltage Directive	
Pushbuttons Selector	UL60079-0 UL60079-1 UL60079-7			
Switches Key Selector Switches Pilot Lights Meters (EU2B-YM)	CAN/CSA C22.2 No. 60079-0 CAN/CSA C22.2 No. 60079-1 CAN/CSA C22.2 No. 60079-7	C UL US	E347230	
	EN60079-0 EN60079-1 EN60079-7 EN60079-31	⟨Ex⟩	PTB 08 ATEX 1053U PTB 08 ATEX 1003U	
	IEC60079-0 IEC60079-1 IEC60079-7 IEC60079-31	IECEX	IECEx PTB 15.0006U IECEx PTB 15.0007U	
Emergency Stop Switches	EN60947-5-5			

**Pilot Light Specifications** 

Rated Insulation Voltage (Ui)	500V						
Rated Operating	6, 12, 24V AC/DC						
Voltage (Ue)	100/110, 115, 120, 200/220 230, 240, 380, 400/440, 480V AC						
Impulse Withstand Voltage (Uimp)	4kV						
Insulation Resistance	100 MΩ minumum (500V DC)						
Frequency	50/60Hz						
Power Consumption	0.3W (24V AC/DC)						
(approx.)	1.5W (100/110V AC)						
Life (reference value)	Approx. 40,000 hours						

 Because the built-in LED lamp is a high-luminance type, the lamp may light dimly due to induction even when the power is off.

### **Switch Specifications**

Switch Spec	Jiii Gati Gii G						
Contact Resistance	50mΩ maximum (initial value)						
Impulse Withstand Voltage (Uimp)	6kV						
Insulation Resistance	100MΩ minimum	(500V DC megger)					
Short-circuit Protection	250V/10A fuse (T	ype aM IEC60269-1/IEC60269-2)					
Conditional Short- circuit Current	1,000A						
	Pushbutton	1,000,000 operations minimum					
	Selector Switch	500,000 operations minimum					
Mechanical Life	Key Selector Switch	500,000 operations minimum					
	Emergency Stop Switch	50,000 operations minimum					
	Pushbutton	250,000 operations minimum (switching frequency 1800 operations/h)					
Electrical Life	Selector Switch	250,000 operations minimum (switching frequency 900 operations/h)					
Electrical Life	Key Selector Switch	250,000 operations minimum (switching frequency 900 operations/h)					
	Emergency Stop Switch	50,000 operations minimum (switching frequency 900 operations/h)					
Minimum Force Required for Direct Action	Emergency Stop Switch	60N					
Minimum Operator Stroke Required for Direct Opening Action	Emergency Stop Switch	7.0mm					
Maximum Operator Stroke	Emergency Stop Switch	9.0mm					

- Contact bounce
- Contacts will bounce during operation of pushbuttons and selector switches (reference value: 20 ms). Be sure to take contact bounce time into consideration when designing a control circuit.
- Replacing the control units, nameplates, padlock covers, and LED lamps by users affect the explosion-proof performance which is not guaranteed. Contact IDEC when replacement is necessary.

### **Contact Ratings**

### IECEx/ATEX/Ex-CCC, TIIS certified

Rated Insula	ation Volta	ge (Ui)	600V				
Rated Therr	mal Currer	nt (Ith)		10/	A (*)		
Rated Oper	ating Volta	ige (Ue)	24V	120V	240V	500V	
	AC	Resistive Load (AC12)	10A (*)	10A (*)	6A	2.8A	
Rated Operating	50/60Hz	Inductive Load (AC15)	10A (*)	6A	ЗА	1.4A	
Current (le)	DC	Resistive Load (DC12)	8A	2.2A	1.1A	_	
		Inductive Load (DC13)	4A	1.1A	0.55A	_	

\* Up to 2 contacts (per control unit): 10A 3 contacts (per control unit): 9A

Minimum applicable load: 3V AC/DC, 5 mA

Applicable operating locations may vary according to operating conditions and load types.

• TÜV ratings (emergency stop switches) AC-15 250V/3A

DC-13 125V/1.1A

• UL/c-UL ratings: 600V/10A

### **Buzzer Specifications (EC9F-Z)**

Rated Insulation Voltage (Ui)	250V
Rated Operation Voltage	110V AC, 220V AC (50/60Hz)
Time Rating	10 minutes
Sound Pressure (at 1m)	80dB minimum
Power	8VA maximum

 If the sound continues longer than the time rating, the internal parts may overheat and explosion-proof characteristics may be impaired.

### Variable Resistor Specifications (EC9E-R)

		` `	
Rated Power	1W or 2.5W (at 40°C	)	
Resistance Range	1, 2, 3, 5, 10kΩ Tolerance: ±10%, Ch	naracteristics	s: Linear
Insulation Resistance	100MΩ minimum (50	0V DC meg	gar)

- To maintain stable performance for a long period of time, use only up to about 50% of the rated power capacity.
- The variable resistor is available on control boxes with wiring.


### Meter Specifications (EU2B-YM/EC9F-M)

Accuracy	Class	2.5 (JIS)		
	Resistance	100 MΩ minimum (500V DC megger)		
	Rated Insulation Voltage (Ui)	300V		
	Operation	Moving core		
AC	Impulse Withstand Voltage (Uimp)	4kV		
Ammeter	Power Consumption	1VA		
	Measurement	5A, 10A, 30A, 50A, etc		
	Input (CT Ratio)	1A, 5A		
	Extended Memory	3 times, etc		
	Rated Insulation Voltage (Ui)	150V		
	Operation	Moving coil		
DC	Impulse Withstand Voltage (Uimp)	2.5kV		
Ammeter	Input	0 to 10V DC, 4 to 20mA DC, etc		
	Power Consumption (DC ammeter)	0.01W		
	Power Consumption (DC voltmeter)	1mA		

- Use a commercially available CT (current transformer) for AC ammeters with consumption current of 10A minimum. Install the CT in a non-hazardous location.
- AC and DC ammeters other than listed above are also available upon request, such as extended scale or red pointer.

# Pointer Zero Adjustment and Red Pointer Adjustment

- Using a flat screwdriver, turn the zero adjustment pointer screw and the red pointer screw (see below).
- Zero adjustment is possible only on AC ammeters. On other meters such as DC voltmeters, DC ammeters, and tachometer, zero adjustment is not possible.



### **Control Units**

#### **Pilot Lights**

			Part	Illumination Color	\\/aiabt		
Shape Symbol		Contact Rating	C terminal style: exposed screw terminal	F terminal style: finger-safe screw terminal	Code *	Weight (approx.)	
		100/110V AC 50/60Hz	EU2B-YL116CD*	EU2B-YL116FD*	R: red G: green	150~	
	PL 200/220V AC 50/60Hz		EU2B-YL126CD*	EU2B-YL126FD*	A: amber Y: yellow W: white	150g	
		24V AC/DC	EU2B-YL122CD*	EU2B-YL122FD*	S: blue PW: pure white	108g	
Dimensions (mm)	C Termina Panel This	al Style ckness 1 to 4.5	F Terminal Style Panel Thickness 1 to 4.5	32.5	X1		
		13.3	13.3		X2		
	ļ	67.7 20.3	67.7	.3 61.4	(All dimen	sions in mm.)	

- Other voltages are available: 6V AC/DC, 12V AC/DC, 115V AC, 120V AC, 230V AC, 240V AC, 380V AC, 400/440V AC, 480V AC, 100/110/120V AC/DC, 230/240V AC/DC. For details, see page 18.
  Because LED illuminated pilot lights have small input currents, they may light due to induction even when the power is off.
- Specify an illumination color code in place of \* in the Part No.

#### **Pushbuttons**

				Contact	Part	t No.	Dutter Calan	\\/a:lat	
Shape	Shape Symbol Operation		Operator	Arrange- ment	C terminal style: exposed screw terminal	F terminal style: finger-safe screw terminal	Button Color Code	Weight (approx.)	
				1NO	EU2B-YB110C∗□	EU2B-YB110F∗□	Blank: supplied with four buttons	68g	
			Flush	1NC	EU2B-YB101C∗□	EU2B-YB101F∗□	(B, G, R, W)	oog	
				1NO-1NC	EU2B-YB111C∗□	EU2B-YB111F∗□	Y: yellow S: blue	92g	
	(PB)	Momen-		1NO	EU2B-YB210C∗□	EU2B-YB210F∗□		70a	
	Р	tary		Extended	1NC	EU2B-YB201C∗□	EU2B-YB201F∗□	B: black G: green	70g
				1NO-1NC	EU2B-YB211C∗□	EU2B-YB211F∗□	R: red	94g	
			Mush-	1NO	EU2B-YB310C∗□	EU2B-YB310F∗□	W: white	76g	
				1NC	EU2B-YB301C∗□	EU2B-YB301F∗□	Y: yellow S: blue	7 by	
			100111	1NO-1NC	EU2B-YB311C∗□	EU2B-YB311F∗□		101g	
Dimensions (mm) Flush (C Terminal Sty	le)	Flush (l	Terminal Style	e)		Extended Mushroom	NO N		
Panel Thickness 1 to	4.5	Panel 1	hickness 1 to	1.5	32.2		4 2	2	
		949		040	88 4 8		3 -	<i>†</i>	
67.7	13.3		67.7	13.3	47.4	19.3	(All dimensi	ons in mm.)	

- Other contact arragements (2NO, 2NC, 1NO-2NC, 2NO-1NC, 3NO, 3NC) are also available. See page 18.
- Specify a button color code in place of \* in the Part No.
  Specify the reducer certification code in place of \_\_\_\_\_. Blank: TIIS certified, -D: IECEx/ATEX/Ex-CCC, UL/c-UL certified

#### **Emergency Stop Switches**

				0	Pari	Dutter	\\/a:ada±	
Shape	Symbol	Operation	Operator	Contact Arrangement	C terminal style: exposed screw terminal	F terminal style: finger-safe screw terminal	Button color	Weight (approx.)
				2NC	EU2B-YBV302CR	EU2B-YBV302FR		120g
主    (一)	Push-to-lock or Turn-to-		ø40 Mushroom	1NO-2NC	EU2B-YBV312CR	EU2B-YBV312FR	Red	1440
$\rightarrow$				3NC	EU2B-YBV303CR	EU2B-YBV303FR		144g
Dimensions (mm)	C Termin	al Style Pa	nel Thickness 1 to	4.5 F Terminal S	tyle Panel Thickness 1	to 4.5	NO N	
						4.8	3	2    -   
	ļ	67.7	35		35	47.4	(All dimensi	ons in mm.)

- Other contact arrangements (1NC, 1NO-1NC) are also available. See page 18 for details.
  Emergency stop switches are only available with a red button.

#### Selector Switches

NC contact: direct opening action (IEC 60947-5-1 Annex K)

		No. of	Contac	t Block		erato			rt No.	Weight	
Shape Syn	Symbol	Posi- tions	Mounting Position	Contact	1	1 2 Operation		C terminal style:	F terminal style: finger-safe screw terminal	(approx.)	
		2-posi-	1	NO		•	Maintained				
		tion	2	_			L R	EU2B-YS211C	EU2B-YS211F	98g	
1		90°	3	NC	•						
	ES				1	0 2					
		3-position 45°	1	NO			Maintained				
			tion ②	2	_			L C R	EU2B-YS320C	EU2B-YS320F	98g
			3	NO		•				1	
Dimensions (mm)	C Termina	•			minal S	-			Operator Position		
	Panel Thic	kness 1 to 4.5	5	Panel Thickness 1 to 4.5					1 1 2	NO NC	
	67.7 27.3					67.7	13.3	8 47.4	① Contact ② Block Position ③	\	
	-	01.1	+ 21.3	-		07.7	+ 21.3	41.4	(All dimen	sions in mm.)	

- Other contact arrangements (2NO, 2NC, 1NO-2NC, 2NO-1NC, 3NO, 3NC) and overlapping contacts are also available.
- Spring return from right, spring return from left, spring return two-way also available. See pages 19 to 20.

#### **Key Selector Switches**

#### NC contact: direct opening action (IEC 60947-5-1 Annex K)

rey coloctor our									ing dotton (iEo ooo ii o	- ,
		No. of	Contac	t Block		rator sition		Pa	rt No.	Maight
Shape	Symbol	Posi- tions	Mounting Position	Contact	1	2	Operation	C terminal style: exposed screw terminal	F terminal style: finger-safe screw terminal	Weight (approx.)
		2-posi-	1)	NO		•	Maintained			
		tion	2	_			L R	EU2B-YSK211CA	EU2B-YSK211FA	120g
		90°	3	NC	•					
	ES	3-posi- tion			1	0 2				
			①	NO			Maintained			
			2	_			L C R	EU2B-YSK320CA	EU2B-YSK320FA	120g
		45°	③ NC			•				
Dimensions (mm)	C Terminal	Style		F Te	rminal	Style		-GL, -UL	Operator Posi	tion
	Panel Thic	kness 1 to 4.5	j <del>»   •</del>	Pa	anel Th	nickness	s 1 to 4.5	_	32.2 C	
67.7 13.3 38.3							13.3	38.3		© Contac © Block Positic © Sions in mm.)
										,

- Other contact arrangements (2NO, 2NC, 1NO-2NC, 2NO-1NC, 3NO, 3NC) and overlapping contacts are also available.
  Spring return from right, spring return from left, spring return two-way also available.
  On the spring-returned, the key can released only from the maintained position. On the maintained, the key can be released from every position.
- Key retained position can be selected. See pages 19 to 20.
- Each key selector switch is supplied with two identical keys. Three different keys are also available.

### Buzzer (for TIIS certified model only) (Cannot be installed on 1 to 3 units x 1 column boxes.)

Shape	Symbol	Rated Power (50/60Hz)	Part No.	Sound Volume (at 1m)	Sound Duration	Power Con- sumption	Weight (approx.)	Dimensions
		110V AC	EC9F-Z11N		1.0			Terminal Screw M4
	BZ	220V AC	EC9F-Z12N	80dB minimum	10 minutes *	8VA maximum	0.4kg	No finger-safe screw terminal model available.

<sup>\*</sup> Do not exceed the sound duration time, otherwise internal heating will result.

### Variable Resistors (for TIIS certified model only) (Cannot be installed on 1 to 5 units × 1 column boxes.)

Shape	Symbol	Resistance Range	Part No.	Rated Power	Insulation Resistance	Weight (approx.)	Dimensions (mm)
6	(R)	1, 2, 3, 5, 10kΩ Tolerance±10% Characteristics: linear	EC9E-R	1W, 2.5W (at 40oC)	100MΩ minimum (500V DC)	0.45kg	60 33 555 99 99 99 99 99 99 99 99 99 99 99 99

- The variable resistor is available on control boxes with wiring.
- Specify resistance value and rated power when ordering.

### Meters (IECEx/ATEX/Ex-CCC, UL/c-UL Certified)

Shape	Sym- bol	Input	Part No.	Specif	ications	Capacity/ Scale Code	Weight (approx.)	Dimensions (mm)
			EU2B-YM53A5△	Capacity: 5A	Expansion scale ×3	5A (3)		
			EU2B-YM53A10△	Capacity: 10/5A	Expansion scale ×3	10/5A (3)		
			EU2B-YM13A10△	Capacity: 10/1A	Expansion scale ×3	10/1A (3)		
			EU2B-YM53A15△	Capacity: 15/5A	Expansion scale ×3	15/5A (3)		
			EU2B-YM13A15△	Capacity: 15/1A	Expansion scale ×3	15/1A (3)		Screw Terminal
		AC input	EU2B-YM13A20△	Capacity: 20/1A	Expansion scale ×3	20/1A (3)		Terminal Screw M3.5
		meter (ammeter)	EU2B-YM53A30△	Capacity: 30/5A	Expansion scale ×3	30/5A (3)		
			EU2B-YM13A30△	Capacity: 30/1A	Expansion scale ×3	30/1A (3)		
			EU2B-YM53A50△	Capacity: 50/5A	Expansion scale ×3	50/5A (3)		60.1 33.5
	(M)		EU2B-YM53A60△	B-YM53A60 △ Capacity: 60/5A Expansion scale ×3 60/1		60/1A (3)	0.01.	
			EU2B-YM53A75△	Capacity: 75/5A	Expansion scale ×3	75/5A (3)	0.3kg	
			EU2B-YM53A100△	Capacity: 100/5A	Expansion scale ×3	100/5A (3)		Finger-safe Screw Terminal
			EU2B-YM53A150△	Capacity: 150/5A	Expansion scale ×3	150/5A (3)		Terminal Screw M3.5
			EU2B-YM010VD△-PER	0-10V DC input	Scale: 0 to 100%	010VD-PER		
			EU2B-YM010VD△-60HZ	0-10V DC input	Scale: 0 to 60Hz	010VD-60HZ		
		DO: 1	EU2B-YM001MD△-PER	0-1mA DC input	Scale: 0 to 100%	001MD-PER		62.1 33.5
		DC input meter	EU2B-YM001MD△-60HZ	0-1mA DC input	Scale: 0 to 60Hz	001MD-60HZ		
		meter	EU2B-YM001MD△-80HZ	0-1mA DC input	Scale: 0 to 80Hz	001MD-80HZ		
			EU2B-YM420MD△-PER	4-20mA DC input	Scale: 0 to 100%	420MD-PER		
			EU2B-YM420MD△-60HZ	4-20mA DC input	Scale: 0 to 60Hz	420MD-60HZ		

- Specify a terminal style in place of △ in the Part No. C: exposed screw terminal), F: finger-safe screw terminal
  Use a commercially available CT (current transformer) for AC ammeters with consumption current of 10A minimum. Install the CT in a non-hazardous location.
  AC and DC ammeters other than listed above are also available upon request.

### Meters (TIIS certified model only) (Cannot be installed on 1 to 3 units × 1 column boxes.)

Shape	Symbol	Input	Part No.	Specifications	Weight (approx.)	Dimensions (mm)
Shape	Symbol	AC input meter ammeter)  DC input meter	Part No.  EC9F-M53A5N EC9F-M53A10N EC9F-M13A10N EC9F-M53A15N EC9F-M13A15N EC9F-M13A20N EC9F-M53A30N EC9F-M53A50N EC9F-M53A50N EC9F-M53A50N EC9F-M53A100N EC9F-M53A100N EC9F-M53A100N EC9F-M53A100N EC9F-M53A100N EC9F-M53A100N EC9F-M010VD-PER EC9F-M010VD-PER EC9F-M01MD-PER EC9F-M01MD-PER	Specifications  Capacity: 5A Expansion scale × Capacity: 10/5A Expansion scale × Capacity: 10/1A Expansion scale × Capacity: 15/5A Expansion scale × Capacity: 15/5A Expansion scale × Capacity: 20/1A Expansion scale × Capacity: 30/5A Expansion scale × Capacity: 30/5A Expansion scale × Capacity: 50/5A Expansion scale × Capacity: 50/5A Expansion scale × Capacity: 60/5A Expansion scale × Capacity: 75/5A Expansion scale × Capacity: 100/5A Expansion scale × Capacity: 150/5A Expansion scale × Capacity: 150/5	(approx.) 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 4 0.3kg	Dimensions (mm)  Terminal Screw M4  Screw M4  No finger-safe screw terminal model available.
			EC9F-M420MD-PER EC9F-M420MD-60HZ	4-20mA DC input Scale: 0 to 100% 4-20mA DC input Scale: 0 to 60Hz		

- Use a commercially available CT (current transformer) for AC ammeters with consumption current of 10A minimum. Install the CT in a non-hazardous location.
  AC and DC ammeters other than listed above are also available upon request.

### **Available Control Units**

**Pilot Lights** 

la a d	Data d Valta na	Part	No.	Illumination Color				
Input	Rated Voltage	Exposed Screw Terminal	Finger-safe Screw Terminal	Code *				
	100/110V AC	EU2B-YL116CD*	EU2B-YL116FD*					
	115V AC	EU2B-YL1116CD*	EU2B-YL1116FD*					
	120V AC	EU2B-YL1126CD*	EU2B-YL1126FD*					
	200/220V AC	EU2B-YL126CD*	EU2B-YL126FD*					
AC	230V AC	EU2B-YL1236CD*	EU2B-YL1236FD*	R: red				
	240V AC	EU2B-YL1246CD*	EU2B-YL1246FD*	G: green				
	380V AC	EU2B-YL1386CD*	EU2B-YL1386FD*	A: amber Y: yellow W: white S: blue				
	400/440V AC	EU2B-YL146CD*	EU2B-YL146FD*					
	480V AC	EU2B-YL1486CD*	EU2B-YL1486FD*					
	6V AC/DC	EU2B-YL166CD*	EU2B-YL166FD*	PW: pure white				
	12V AC/DC	EU2B-YL111CD*	EU2B-YL111FD*					
AC/DC	24V AC/DC	EU2B-YL122CD*	EU2B-YL122FD*					
	100/110/120V AC/DC (Note 1)	EU2B-YL1110CD*	EU2B-YL1110FD*					
	230/240V AC/DC (Note 1)	EU2B-YL1240CD*	EU2B-YL1240FD*					

<sup>•</sup> Specify a color code in place of \* in the Part No. Note 1: For IECEx/ATEX/Ex-CCC, UL/c-UL

#### **Pushbuttons**

0	0	Contact	Part	t No.	Dutter Calau Cada	
Operator	Operation	Arrangement	Exposed Screw Terminal	Finger-safe Screw Terminal	Button Color Code *	
		1NO	EU2B-YB110C∗□			
		1NC	EU2B-YB101C∗□	EU2B-YB101F∗□		
		1NO-1NC	EU2B-YB111C∗□	EU2B-YB111F∗□	Blank: supplied with B	
		2NO	EU2B-YB120C∗□	EU2B-YB120F∗□	(black), G (green), R (red)	
Flush	Momentary	2NC	EU2B-YB102C∗□	EU2B-YB102F∗□	and W (white) buttons.	
		2NO-1NC	EU2B-YB121C∗□	EU2B-YB121F∗□	Y: yellow	
		1NO-2NC	EU2B-YB112C∗□	EU2B-YB112F∗□	S: blue	
		3NO	EU2B-YB130C∗□	EU2B-YB130F∗□		
		3NC	EU2B-YB103C∗□	EU2B-YB103F∗□		
		1NO	EU2B-YB210C∗□	EU2B-YB210F∗□		
		1NC	EU2B-YB201C∗□	EU2B-YB201F∗□		
		1NO-1NC	EU2B-YB211C∗□	EU2B-YB211F∗□	B: black	
		2NO	EU2B-YB220C∗□	EU2B-YB220F∗□	G: green	
Extended	Momentary	2NC	EU2B-YB202C∗□	EU2B-YB202F∗□	R: red W: white	
		2NO-1NC	EU2B-YB221C∗□	EU2B-YB221F∗□	Y: yellow	
		1NO-2NC	EU2B-YB212C∗□	EU2B-YB212F∗□	S: blue	
		3NO	EU2B-YB230C∗□	EU2B-YB230F∗□		
		3NC	EU2B-YB203C∗□	EU2B-YB203F∗□		
		1NO	EU2B-YB310C∗□	EU2B-YB310F∗□		
		1NC	EU2B-YB301C∗□	EU2B-YB301F∗□		
		1NO-1NC	EU2B-YB311C∗□	EU2B-YB311F∗□	B: black	
40		2NO	EU2B-YB320C∗□	EU2B-YB320F∗□	G: green	
ø40 Mushroom	Momentary	2NC	EU2B-YB302C∗□	EU2B-YB302F∗□	R: red W: white	
WIGGIIIOOIII		2NO-1NC	EU2B-YB321C∗□	EU2B-YB321F∗□	Y: yellow	
		1NO-2NC	EU2B-YB312C∗□	EU2B-YB312F∗□	S: blue	
		3NO	EU2B-YB330C∗□	EU2B-YB330F∗□		
		3NC	EU2B-YB303C∗□	EU2B-YB303F∗□		

#### **Emergency Stop Switches**

Operator	Contact Awangament	Part No.					
Operator	Contact Arrangement	Exposed Screw Terminal	Finger-safe Screw Terminal				
	1NC	EU2B-YBV301CR	EU2B-YBV301FR				
40	1NO-1NC	EU2B-YBV311CR	EU2B-YBV311FR				
ø40 Mushroom	2NC	EU2B-YBV302CR	EU2B-YBV302FR				
Widshiloom	1NO-2NC	EU2B-YBV312CR	EU2B-YBV312FR				
	3NC	EU2B-YBV303CR	EU2B-YBV303FR				

<sup>•</sup> Emergency stop switches are only available with a red button.

Specify a color code in place of \* in the Part No.
 Specify explosion-proof certification code in place of □ in the Part No. -D: IECEx/ATEX/Ex-CCC, UL/u-CL, Blank: TIIS,

Selector Switches (2-position)

	0		Ope		,	F	Part No.		
ļ į	Contact	RIOCK	Posi		Selector	r Switch	Key Selec	tor Switch	
No. of Positions	Mount- ing Position	Con- tact	L	R	Maintained (90°)			Spring return from right (60°)	△: Terminal
	①	NO		•					
	2				EU2B-YS210△	EU2B-YS2110△	EU2B-YSK210△♦	EU2B-YSK2110△B	
	<u>3</u>								
	②				EU2B-YS201△	EU2B-YS2101△	EU2B-YSK201△♦	EU2B-YSK2101△B	
	3	NC	•						
	①	NO		•					
	3	NO		•	EU2B-YS220△	EU2B-YS2120△	EU2B-YSK220△♦	EU2B-YSK2120△B	
ے	①	NC	•	_					
2-position	2	INC			EU2B-YS202△	EU2B-YS2102△	EU2B-YSK202△♦	EU2B-YSK2102△B	
l ő	3	NC	•						
	① ②	NO		•	EU2B-YS211△	EU2B-YS2111△	EU2B-YSK211△◇	EU2B-YSK2111△B	C: Exposed screw
09	3	NC	•		EU2D-13211	EU2D-132111	EU2D-13K211AV	EU2D-13K2111\(\triangle\)D	terminal
2-position/60°	0	NO		•					F: Finger-safe
∺	2	NO		•	EU2B-YS230△	EU2B-YS2130△	EU2B-YSK230△♦	EU2B-YSK2130△B	screw terminal
Ιő	3	NO		•					
2-5	①	NC	•						
06	2	NC	•		EU2B-YS203△	EU2B-YS2103△	EU2B-YSK203△♦	EU2B-YSK2103△B	
<u></u> $\bar{o}$	3	NC	•						
	① ②	NO NO		•	EU2B-YS221△	EU2B-YS2121△	EU2B-YSK221△♦	EU2B-YSK2121△B	
	3	NC	•		LUZD-13ZZ1	LU2D-132121	LUZD-TORZZIAV	LUZD-TUKZIZIAD	
	0	NO		•					
	2	NC	•		EU2B-YS212△	EU2B-YS2112△	EU2B-YSK212△♦	EU2B-YSK2112△B	
	3	NC	•						
	1	NO							
	2	NO			EU2B-YS2R11△	_	EU2B-YSK2R11△♦	_	
	3	NC							

- $\hline \bullet \text{ Specify a terminal style in place of } \triangle \text{ in the Part No. C: exposed screw terminal, F: finger-safe screw terminal}$
- ullet Specify a key removable position code in place of  $\Diamond$  in the Part No. See below for details.

### Selector Switches (2-position/inverse cam)

Suc	SUO Contact Block		Ope	rator	Pa	art No.			
Positions	Contact	Block	Posi		Selector Switch	Key Selector Switch			
of P	Mount-				Maintained (90°)	Maintained (90°)	$\triangle$ : Terminal		
No. o	ing Position	Con- tact	L	R	L R	L R			
	0	NO	•						
	2				EU2B-YS2J10△	EU2B-YSK2J10△♦			
	3								
	0				FLIOR VOC IO4	FLIOR VOICE IO4 A A			
	3	NO			EU2B-YS2J01△	EU2B-YSK2J01△♦			
	0	NC NO	•	_					
	② ②	INO			EU2B-YS2J20△	EU2B-YSK2J20△◇			
	3	NO	•		EU2D-132J2U	EU2D-13K2J2UAV			
	0	NC		•					
_	2	110			EU2B-YS2J02△	EU2B-YSK2J02△◇			
.⊡	3	NC		•	1025 102002	LOLD TOTAL V	C: Exposed screw terminal		
2-position	1)	NO	•						
۱ĕ	2				EU2B-YS2J11△	EU2B-YSK2J11△♦			
	3	NC		•			F: Finger-safe		
06	0	NO	•				screw terminal		
"	2	NO	•		EU2B-YS2J30△	EU2B-YSK2J30△◇			
	3	NO	•						
	0	NC		•					
	2	NC		•	EU2B-YS2J03△	EU2B-YSK2J03△♦			
	3	NC	•	•					
	① ②	NO			FLIOD VCO IO1 A	FLIOD VOKO IO1 A A			
	3	NO NC	_	•	EU2B-YS2J21△	EU2B-YSK2J21△♦			
	0	NO	•						
	2	NC		•	EU2B-YS2J12△	EU2B-YSK2J12△◇	<u> </u>		
	3	NC		•	L02D-102012				

- ullet Specify a terminal style in place of  $\triangle$  in the Part No. C: exposed screw terminal), F: finger-safe screw terminal
- Specify a key removable position code in place of  $\Diamond$  in the Part No. See the details at right.

#### **Positions**

(2-position, 2-position/inverse cam)

Key Selector Switch Selector Switch Operator Position Operator Position 1 Contact
Block
Position Contact ② Block Position

### **Key Removable Positions**

(2-position, 2-position/inverse cam)

z podition, z podition, invoice cam,												
: Key Removable Position												
A: key remov- able in all positions	B: key remov- able at left	C: key remov- able at right										
0 0	0 0	0 2										

@: Key removable

● ②: Key retained

### Selector Switches (3-position)

SU	Cont	act	Op	era	tor				Pa	art No.			
Ì₽	Blo	ck	Po	siti	on		Selector	r Switch			Key Selec	tor Switch	
No. of Positions	Mount- ing Posi- tion	Con- tact	1	0	2	Maintained L C R	Spring return from right	Spring return from left	Spring return two way	Maintained  L C R	Spring return from right	Spring return from left	Spring return two way
	① ② ③	NO NO	•		•	EU2B- YS320∆	EU2B- YS3120△	EU2B- YS3220∆	EU2B- YS3320∆	EU2B- YSK320△◇	EU2B- YSK3120△◇	EU2B- YSK3220△◇	EU2B- YSK3320△◇
	① ② ③	NO NO	•		•	EU2B- YS320N1△	EU2B- YS3120N1△	EU2B- YS3220N1△	EU2B- YS3320N1△	EU2B- YSK320N1△◇	EU2B- YSK3120N1△◇	EU2B- YSK3220N1△◇	EU2B- YSK3320N1△◇
	① ② ③	NC NC				EU2B- YS302△	EU2B- YS3102△	EU2B- YS3202△	EU2B- YS3302△	EU2B- YSK302△◇	EU2B- YSK3102△◇	EU2B- YSK3202△◇	EU2B- YSK3302∆♦
	① ② ③	NC NC		•		EU2B- YS302N1△	EU2B- YS3102N1△	EU2B- YS3202N1△	EU2B- YS3302N1△	EU2B- YSK302N1△◇	EU2B- YSK3102N1△◇	EU2B- YSK3202N1△◇	EU2B- YSK3302N1△◇
	① ② ③	NO NC	•			EU2B- YS311△	EU2B- YS3111△	EU2B- YS3211△	EU2B- YS3311∆	EU2B- YSK311△◇	EU2B- YSK3111∆♦	EU2B- YSK3211△◇	EU2B- YSK3311△◇
Ē	① ② ③	NC NO			•	EU2B- YS311N1△	EU2B- YS3111N1△	EU2B- YS3211N1△	EU2B- YS3311N1△	EU2B- YSK311N1△◇	EU2B- YSK3111N1△◇	EU2B- YSK3211N1△◇	EU2B- YSK3311N1△◇
3-position	① ② ③	NO NC	•	•		EU2B- YS311N2△	EU2B- YS3111N2△	EU2B- YS3211N2△	EU2B- YS3311N2△	EU2B- YSK311N2△◇	EU2B- YSK3111N2△◇	EU2B- YSK3211N2△◇	EU2B- YSK3311N2△◇
က	① ② ③	NC NO		•	•	EU2B- YS311N3△	EU2B- YS3111N3△	EU2B- YS3211N3△	EU2B- YS3311N3△	EU2B- YSK311N3△◇	EU2B- YSK3111N3△◇	EU2B- YSK3211N3△◇	EU2B- YSK3311N3△◇
	① ② ③	NO NC	•		•	EU2B- YS311N4△	EU2B- YS3111N4△	EU2B- YS3211N4△	EU2B- YS3311N4△	EU2B- YSK311N4△◇	EU2B- YSK3111N4△◇	EU2B- YSK3211N4△◇	EU2B- YSK3311N4△◇
	① ② ③	NO NO	•		•	EU2B- YS330∆	EU2B- YS3130△	EU2B- YS3230△	EU2B- YS3330△	EU2B- YSK330△◇	EU2B- YSK3130△◇	EU2B- YSK3230△◇	EU2B- YSK3330△◇
	① ② ③	NC NC NC				EU2B- YS303∆	EU2B- YS3103△	EU2B- YS3203△	EU2B- YS3303△	EU2B- YSK303△◇	EU2B- YSK3103△◇	EU2B- YSK3203△◇	EU2B- YSK3303△◇
	① ② ③	NO NC NO	•	•	•	EU2B- YS321N1△	EU2B- YS3121N1△	EU2B- YS3221N1△	EU2B- YS3321N1△	EU2B- YSK321N1△◇	EU2B- YSK3121N1△◇	EU2B- YSK3221N1△◇	EU2B- YSK3321N1△◇
	① ② ③	NC NO NC	•		•	EU2B- YS312N1△	EU2B- YS3112N1△	EU2B- YS3212N1△	EU2B- YS3312N1△	EU2B- YSK312N1△◇	EU2B- YSK3112N1△◇	EU2B- YSK3212N1△◇	EU2B- YSK3312N1△◇


ullet Specify a terminal style in place of  $\triangle$  in the Part No. C: exposed screw terminal), F: finger-safe screw terminal

### Key Removable Positions (2-position)

♦: Key Removable Position							
A: key removable in all positions	B: key removable in right and center	C: key removable at center and right	D: key removable in center				
0 0 2	0 0	0 0 2	0 0				
E: key removable at left and right	G: key removable at left	H: key removable at right					
0 2	0 0	<b>0</b> ②					

Spring return from right	Spring return from left	Spring return two-way
© © •	0 0 2	<b>9</b>


①①②: Key removable **①①②:** Key retained



ullet Specify a key removable position code in place of  $\Diamond$  in the Part No. See below for details.

# Accessories

### Plate Lock Padlock Cover



### **Pushbutton Cover**

Shape	Part No.	Dimensions (mm)	Remarks
Material: SUS304	EU9Z-BC	60 (43) 5 (32.6) (33.9) (33.9)	Used to protect the EU2B-YB push-button from inadvertent operation.  Mounted by screwing on the control box and cannot be retrofit.  Cannot be used for TIIS or UL/c-UL certified model.

### **Emergency Stop Switch Padlock Cover**

Shape	Part No.	Dimensions (mm)	Remarks
Coating: yellow Material: SUS304	EU9Z-PCE	Base 50 55.4 32.2	Used with EU2B-YBV emergency stop switch to maintain the switch in the latched status.

#### Selector Switch Padlock Cover

Chana	Dowl No.	Lock P	osition	Dimensis	()	Damada
Shape	Part No.	2-position	3-position	Dimensions (mm)		Remarks
EU9Z-PC21	EU9Z-PCS21	Left	Left	60	(44.9)	
EU9Z-PC30	EU9Z-PCS30	_	Center	60	(44.9)	Used with EU2B-YS selector switch to maintain the switch in the selected lock status.  Mounted by screwing on the
	EU9Z-PCS22	Right	Right	60	(44.9) (44.9) (44.9)	control box and cannot be later.  • Cannot be used for TIIS or UL/c-UL certified model.
Material: SUS304	EU9Z-PCS2X	Left Right	Left Right	60	(44.9)	

### **Pushbutton Rubber Boots**

Shape	Part No.	Button Type	For use with nameplate	Rubber boot on pushbutton	Remarks
Material: Silicone rubber	EU9Z-DB1	Flush	No		
Material: Silicone rubber	EU9Z-DB1N	Flush	Yes	Flush pushbutton	Used to protect the button of flush/extended pushbuttons.
Material: Silicone rubber	EU9Z-DB2	Extended	No		Cannot be used on TIIS certified models.
Material: Silicone rubber	EU9Z-DB2N	Extended	Yes	Extended pushbutton	

### Control Box Shade

Chana	Dort No.	Appliable Central Boy	Di	imensions (m	m)
Shape	Part No.	Applicable Control Box	Н	W	D
	EC9Z-F2A21M	EC2B-11 B	180	160	160
		EC2B-21 B	100		
	EC9Z-F2A31M	EC2B-31 B	230	160	160
D > w	EC07 E0461	EC2B-41 B	360	160	160
W	EC9Z-F2A51	EC2B-51 B	360		160
н	EC9Z-F2A32	EC2B-22 B	260	420	160
	EU9Z-FZA3Z	EC2B-32 □ B	260		
	EC9Z-F2A52	EC2B-42 B	360	420	160
Matarial atainlass atasl		EC2B-52 B			
Material: stainless steel Thickness: 1mm	EC9Z-F2A33	EC2B-23 B	260	510	160
Photo: Part No. EC9Z-F2A52	EU9Z-FZA33	EC2B-33 □ B	200	510	
	EC07 E0459	EC2B-43 □ B	360	510	160
	EC9Z-F2A53	EC2B-53 B	300	310	100
	EC9Z-F2A63	EC2B-63 B	410	510	160
	EC9Z-F2A64	EC2B-64 B	410	580	160

- Protects control units from direct sunlight and rain.
- The surface of the control box shade is uncoated.
- Can be installed by tightening to the mounting tabs on the control box.
- Control box shade cannot be installed later. Specify shade at time of order.

### **Nameplates**

### **Control Unit Nameplates**

Shape	Part No.	Dimensions (mm)	Remarks
<b>&gt;</b>	EU9Z-NM	40 Marking Plate (35) 45 45	Used for pilot light, pushbutton, selector switch, and key selector switch (only EU9Z-NP marking plates can be used on EU9Z-NM control unit nameplates).

Marking Plates for Control Unit Nameplates

Shape	Legend	Part No.
HAND OFF AUTO	Blank	EU9Z-NP0
ON	ON	EU9Z-NP1
OFF	OFF	EU9Z-NP2
START	START	EU9Z-NP3
	STOP	EU9Z-NP4
STOP	OFF-ON	EU9Z-NP31
Material: aluminum (35×6.5×1mm)	HAND-AUTO	EU9Z-NP35
(White legends on black background)	HAND-OFF-AUTO	EU9Z-NP53

<sup>•</sup> When other legends are needed, order blank nameplate and engrave.

### **Emergency Stop Switch Nameplate Sticker**

Shape	Legend	Part No.	Dimensions (mm)
	① Blank	EU9Z-NVS0	© ©
Material: synthetic paper Background: yellow Legend: black	② EMERGENCY STOP	EU9Z-NVS27	040,5

### **Maintenance Parts**

### Lens

Shape	Color	Part No.
	Red	EU9Z-LR
	Green	EU9Z-LG
	Amber	EU9Z-LA
	Yellow	EU9Z-LY
	Blue	EU9Z-LS
	White	EU9Z-LW (*)

<sup>\*</sup> Used for W (white) and PW (pure white) illumination.

#### **Buttons**

Shape		Button Shape	Part No.	Button Color Code
0 2 3		① Flush	HW1A-B1□	Specify a color code in place of □ in the
		② Extended	HW1A-B2□	Ordering No. B: black S: blue
		③ ø40 Mushroom	HW1A-B4□	G: green W: white R: red Y: yellow

**Control Unit Mounting Hole Plug** 

Shape	Part No.	Dimensions (mm)	Remarks
	EU9Z-BP	23.2 13.3 1.0 to 10.5 (panel thickness)	<ul> <li>Used to plug unused mounting holes (ø30.5) on the mounting panel.</li> <li>See page 24 for TIIS certified mountable control boxes.</li> <li>Not mountable on 1 contact block type of -GL, -U models.</li> </ul>

### **TIIS Certified Models**

Box	Control Unit			No. of	Mountal	ole Contr	ol Units			No. of	Control Unit	TIIS Type Test			
Size	Configura- tion	PL	PB	ES	SS	M	BZ	<b>VR</b>	BP	Units	Terminal	Aproval No.			
	01, 02	1	1	1							С	TC19254			
11	01,02	'	ı	'	_					1	F	TC19255			
- 11	06				1	_	_	_	_	'	С	TC19256			
	06	_		_	1						F	TC19257			
	01 00 10	2	2	2	_						С	TC19254			
	01, 02, 10	2	2	2	_						F	TC19255			
21	04	_	2	2	2				_	_	_	2	С	TC19256	
21	04	_	2	2	2	_	_	_				_	2	F	TC19257
	06, 17	2	_	_	2								С	TC19258	
	00, 17	2	_	_	2						F	TC19259			
31		3	3	3	3					3	С	TC19260			
31		3	3	3	3	_	_	_	_	3	F	TC19261			
41		4	4	4	4	1	1	_	3	4	C/F	TC19262			
51		5	5	5	5	1	1	_	4	5	C/F	1019202			
22		4	4	4	4	2	2	2	3	4	C/F	TC19263			
32		6	6	6	6	2	2	2	5	6	C/F	1019203			
42	Any	8	8	8	8	2	2	2	7	8	C/F	TC19264			
52	Ally	10	10	10	10	2	2	2	9	10	C/F	1019204			
23		6	6	6	6	3	3	3	5	6	C/F	TC19265			
33		9	9	9	9	3	3	3	8	9	C/F	1019203			
43		12	12	12	12	3	3	3	11	12	C/F	TC19266			
53		15	15	15	15	3	3	3	14	15	C/F	1019200			
63		18	18	18	18	3	3	3	17	18	C/F	TC19267			
64		24	24	24	24	4	4	4	23	24	C/F	TC19268			


PL: Pilot lights (EU2B-YL), PB: Pushbuttons (EU2B-YB), ES: Emergency stop switches (EU2B-YBV),

SS: Selector switches (EU2B-YS), Key Selector Switches (EU2B-YSK), M: Meter KS (EC9F-M), BZ: Buzzer (EC9F-Z),

VR: Variable resistor (EC9E-R), BP: Control unit mounting hole plug (EU9Z-BP), -: not mountable

### TIIS Certified Models Part No. Development

These part numbers are marked on TIIS certificate and product label, and not ordering no.



## Safety Precautions

- · Use explosion-proof electrical equipment that are applicable for use in hazardous areas (potentially explosive atmosphere where explosive gas or vapor may exist), otherwise explosion or fire hazard may result.
- EC2B control boxes can be installed only in zones 1 and 2. Do not use in zone 0. In North America, the EC2B can be installed in Division 2 areas, but cannot be installed in Division 1 areas.
- Turn power off to the EC2B control box before installation, removal, wiring, or maintenance, otherwise explosion, fire hazard, or electric shock may result.
- Special skills and knowledge of explosion protection, electric system installation, and relevant laws/regulations are required to transport, install, wire, operate, repair, and inspect the EC2B control box. People without such expertise must not use the EC2B control box, otherwise damage or accident may result.
- Do not modify the EC2B, otherwise damage or accident may result.
- Do not use a damaged EC2B control box, otherwise damage or accident may result.
- When connecting external devices, make sure that each cable is connected to the correct terminal, otherwise electric shock, fire hazard, or explosion may result.
- Use wires of a proper size to meet voltage and current requirements. Incorrect wiring may cause abnormal temperature rise and lead to fire hazard and explosion.
- Connect the grounding terminal to a proper ground, otherwise electric shock, fire hazard, or explosion may result.
- Do not sit on or hang from the EC2B control box, otherwise damage, personal injury, or accident may result.

- Do not open the lid of the EC2B control box when it is energized, otherwise electric shock, fire hazard, or explosion may result.
- Operate the EC2B control box at the rated current and voltage specified in this catalog, otherwise short-circuiting, fire hazard, or explosion may result.
- When measuring the insulation resistance of the EC2B control box, make sure that potentially explosive atmosphere of explosive gas or vapor does not exist in the vicinity, otherwise explosion may result. Also, do not touch the terminals without paying attention, otherwise electric shock will result.
- Do not place any obstacles in front of the nameplate.
- Do not remove the nameplate.
- When opening the lid for wiring, maintenance or inspection, make sure that substances such as dust, concrete powder, or metal powder do not enter inside the box, otherwise contact failure or insulation failure may result.
- Do not drop the EC2B control box during transportation.
- Be sure to open the carton the right way up, otherwise damage or personal injury may result.
- Check that the product is what you have ordered. Using an incorrect model might result in malfunction or acci-
- Stop operation immediately if abnormal operation occurs. Otherwise, a secondary accident may occur.
- The surface temperature of the EC2B control box may become extremely hot during operation. Before maintenance or inspection of the EC2B, be sure to wear gloves to prevent burning your hand.

# Operating Instructions

- · Notes on Use
- Installation Area
- Do not install the EC2B control box in an environment where more than IP65 protection degree (more than Type 4X in North America) is required.
- Use the EC2B control box under ambient temperature of -20 to +50°C. If the control box is exposed to direct sunlight and the surface temperature may rise above 50°C, provide a shade (see page 22) to keep the surface temperature below 50°C.
- Installation
- Wall mount
  - Use four M6 bolts for 1-column, four M8 bolts for 2- and 3-column, or other methods with equivalent strength to install the control box. Mounting tab thickness is 1.5mm for 1 column and 2mm for 2, 3, and 4 columns. (See dimensions) (See dimensions.)
- Pole mount
  - Use four M12 bolts or other methods with equivalent strength to install the control box.
  - Use flat washers to prevent scratches on the pole base coating.

- If bolts become may loose due to vibration, use spring washers.
- If bolt corrosion is anticipated, use anti-corrosion bolts or other countermeasures.
- Notes on Emergency Stop Switches
- When using the emergency stop switches on safety-related parts of the control system, observe safety standards and regulations of the relevant country or region. Also be sure to perform a risk assessment before operation.
- Opening/Closing the Lid
- Use a Philips screwdriver to loosen lid mounting screws. While holding the unhinged side, open the lid slowly without exerting excessive force on the hinge.
- Before closing the lid, make sure of the following:
- No foreign substances are on the packing or joint sur-
- No displacement of the waterproof packing.
- Wires are not caught between the joint surfaces.
- Next, close the lid slowly and tighten the screws to a proper torque of 1.6 to 2.4 N·m.

### **Operating Instructions**

#### Limitation of the Operating Current

- Major heat sources comes from the wiring which is connected to the control box. Therefore, not only the operating current but wiring conditions (size, no. of wires, no. of wire bundles) may cause temperature rise. When wiring, observe the following conditions.
  - Stranded wire: 1.5 to 2.5 mm² (UL-c-UL certified) 1.25 to 2.5 mm² (other)

solid wire: ø1.2 to ø1.6 mm (16 to 14 AWG)

- · Maximum no. of wires per bundle: 16
- · Maximum operating current: 10A
- When using the control box under operating environment of 40°C minimum, use a heat resistant cable of 70°C minimum.
- Determine the operating current so that the total heat value of 1 wire bundle is below 300 [A<sup>2</sup> × wires]. Also, when calculating the heat value, take the current fluctuation (10%) into consideration.

[calculation example: EC2B-41\*\*B (8 circuit)]

 $\{(10A \times 1.1)^2 \times 2 \text{ wires}\} + \{(1A \times 1.1)^2 \times 14 \text{ wires}\} \approx 259$ 

(can be used because < 300)

②Apply 10A to 1 circuit, 2A to the remaining 7 circuits:

 $\{(10A \times 1.1)^2 \times 2 \text{ wires}\} + \{(2A \times 1.1)^2 \times 14 \text{ wires}\} \approx 310$  (cannot be used because > 300)

2. See the table below for the allowable operating current when applying current evenly to each control box.

Control Box Part No.	Max. No. of Circuits	Max No. o Bund [wires] ([wire Without	Allowable Operating Current (reference)	
		terminal blocks	terminal blocks	(*2)
EC2B-11 B	3	16 (16×1)	8 (8×1)	7A
EC2B-21 B	6	16 (16×1)	8 (8×1)	5A
EC2B-31 B	9	16 (16×1)	8 (8×1)	4A
EC2B-41 B	12	16 (16×1)	16 (16×1)	3A
EC2B-51 B	15	16 (16×1)	16 (16×1)	3A
EC2B-22□B□	12	32 (16×2)	16 (8×2)	5A
EC2B-32 B	18	32 (16×2)	16 (8×2)	4A
EC2B-42□B□	24	32 (16×2)	32 (16×2)	3A
EC2B-52 B	30	32 (16×2)	32 (16×2)	3A
EC2B-23 B	18	48 (16×3)	24 (8×3)	5A
EC2B-33□B□	27	48 (16×3)	24 (8×3)	4A
EC2B-43□B□	36	48 (16×3)	48 (16×3)	3A
EC2B-53 B	45	48 (16×3)	48 (16×3)	3A
EC2B-63 B	54	48 (16x3)	48 (16x3)	3A
EC2B-64 B	72	64 (16x4)	64 (16x4)	3A

- \*1: Make sure that the number of wires per bundle is a maximum of 16 by reducing the wiring or by jumper wiring. The maximum number of wires per bundle may need to be further reduced depending on the wire size, lead-in fitting, or conduit size.
- \*2: The allowable current value (reference) when applying current evenly to all circuits of the maximum number of circuits.

#### Wiring Construction

- Observe the laws and regulations in each country concerning wiring construction.
- Use cable wiring or metal conduit wiring for installation in hazardous locations. If foreign objects or water may enter the box, install a sealing fitting near the cable entry of the box and seal the control box using a compound.
- Standard type control boxes do not contain a terminal block. Wire the control units directly.

## **Operating Instructions**

### Wiring

#### **Applicable Wires**


Stranded wire: 1.25 to 2.5 mm<sup>2</sup>, solid wire: ø1.2 to ø1.6 mm (AWG16 to 14)


• Do not connect more than 2 wires to the same terminal.

#### Applicable crimping terminal


- Ring terminals cannot be used for EU2B control units with IP20 finger-safe terminals.
- Ring and spade terminals cannot be used for IP20 clamp type terminal blocks.
- When connecting 2 ferrules to an EU2B control unit, use ferrules without insulating sheath.

#### For control units EU2B







#### For control units EC9



### For screw terminal ET2A-8PE For IP20 clamp terminal

# (WAGO: 264-238)






· Recommended crimping terminal (WAGO) Ferrule with insulating sheath: 216-204 Ferrule without insulating sheath: 216-104 Crimping plier: 206-204

#### **Recommended Tightening Torque**

EU2B control units (M3.5) and ET2A-8PE terminal block (M4): 1.0 to 1.3 N·m

# Warning

Incorrect wiring may cause fire hazard. Observe the following conditions.



- Be sure to install an insulating sheath on the crimping terminal or the crimping terminal with insulation.
- When connecting solid wires or stranded wires directly, strip the insulation as mentioned below, and insert the wire all the way in.

EU2B Control units: 8.6 mm maximum IP20 crimping terminal: 8 to 9 mm

- When using stranded wires, make sure that there are no wire whiskers.
- Make sure that the spade crimping terminals and ferrules are inserted all the way in.
- Use insulated ring terminals for the ET2A-8PE terminal block. Use only applicable crimping terminals and do not directly connect stranded wires or solid wires.

# **Operating Instructions**


### Removing and Installing the Contact Unit/ Lamp Unit

#### Removing the Contact Unit/Lamp Unit

To remove the contact unit or the lamp unit from the operator, pull the protruding part of the locking lever outwards as shown in the figure below (using a screwdriver, etc.) and turn it to the left. The contact unit or lamp unit can be pulled out.

#### **Emergency stop switch**


Note that when contact unit is detached from the operator part, the NO contact is closed and NC contact is open. Do not move the lock lever when the contact unit is detached (red indicator is protruded), otherwise the switch will be damaged.



#### Installing the Contact Unit/Lamp Unit


To install the contact unit, place the TOP marking on the operator and the TOP marking on the contact block adaptor in the same direction, and then attach the contact unit to the operator as shown in the figure below. Then turn the locking lever to the right. Follow the same procedure when installing the lamp unit.

 When installing the lamp unit, check that the inner lens is not loose. Note that the contact units of the emergency stop switch and pushbutton/selector switch are not interchangeable.



#### **Removing the Contact Block**

To remove the contact block, insert a flat screw-driver under the latch of the contact block adaptor and disengage the latch as shown in the figure below.



When installing the contact block after mainte-

nance or wiring, make sure that the contact configuration is correct. Installing the contact block in an incorrect position or incomplete installation may cause malfunction of the switch.

Make sure to remove the contact block from the operator before installing the contact block to the contact block adaptor. Also make sure that the contact block is correctly installed to the contact block adaptor before attaching the operator. Do not install the contact block adaptor with the operator attached. Otherwise, malfunction may result.

### **Protective Grounding**

Protective grounding must be performed according to the installation environment and rating requirements. Observe laws and regulations set by each country.

- Connect the M4 grounding terminal of the EC2B control box to a proper ground (grounding resistance  $10\Omega$  maximum). When operating the EC2B control box by connecting to circuits of 300V or below, the grounding resistance must be  $100\Omega$  maximum.
- When using cables, connect one of the cable cores to the grounding terminal in the enclosure.
- If the grounding terminal in the enclosure cannot be used, use the M4 grounding terminal on the outside of the enclosure for wall mount, or the M6 grounding terminal of the pole base for pole mount.
   Recommended tightening torque:

M4: 1.0 to 1.3 N·m M6: 3.9 to 5.4 N·m

For grounding, use appropriate wires (size, material, insulation) that can tolerate the expected maximum grounding current. Be sure to protect the grounding wire with protection, such as metal conduit, from external damage.

### Maintenance and Inspection

- Observe laws and regulations set by each country.
- Do not open the lid when inspecting the EC2B while it is energized.
- Never disassemble the control box.
- Do not use tools that cause sparks during maintenance and inspection.
- When using measuring devices, use explosion-protected types.
- When the EC2B needs to be disassembled or assembled for maintenance or repair, contact IDEC.

### Disposal

Observe laws and regulations set by each country concerning refuse disposal.



**TO: IDEC Corporation** 

# EC2B

# 1-column Control Box Specification Sheet

	Company:				TE	L:				No. of C	ontrol Box	
	Contact Per	rson:			FA:	X:				_		
Salact the requir			acking the check	hoves (								
	Select the required specifications by checking the checkboxes ( // ), and specify the details.											
1. Certifica	ation		□ IECEx/AT	EX/E>	(-CCC		JL/c-l	JL, IECE	x/ATE	X		
2. Control	2. Control box size (wall mount only)											
	C2B-110		☐ EC2B-210		☐ EC2B-310	)		C2B-410	)	□ EC2B-	510	
	Nameplate							NP		NP (1)		
	NP -							$\begin{bmatrix} 1 \\ 2 \end{bmatrix}$		(T)(W)(S)(W)(W)(W)(W)(W)(W)(W)(W)(W)(W)(W)(W)(W)		
	(1) E1		② E <sub>1</sub>									
						1		4 E2		[5]	E2	
								<u> </u>				
3. Namep	Leg	end co	olor: black letter, w	vhite bac								
	Max	kimum	no. of letters: 19	letters pe	er line (up to 2 lines)		st line					
☐ No nam	☐ 1 line neplate	Э			□ 2	lines 2	 nd line					
4. Control		Init Pa	rt No			Contro	ol Unit Na	menlate				
	oonard C	Jille F u		□ ON	□ OFF		START	□ STOP		ERGENCY STOP		
(1)				□ OFF		TO □ ecify lette		FF AUTO	□ Blar	nk N		
				□ ON	□ OFF		START	□ STOP		RGENCY STOP		
2				□ OFF ON □ HAND AUTO □ HAND OFF AUTO □ Blank								
				□ No nameplate □ Specify letters ( ) □ ON □ OFF □ START □ STOP □ EMERGENCY STOP								
3				□ OFF ON □ HAND AUTO □ HAND OFF AUTO □ Blank								
				□ No nameplate □ Specify letters ( )  □ ON □ OFF □ START □ STOP □ EMERGENCY				) ERGENCY STOP				
(4)				□ OFF ON □ HAND AUTO □ HAND OFF AUTO □ Blank								
				□ No nameplate □ Specify letters ( )								
5				□ ON	□ OFF ON □ HAND AU		START HAND O	□ STOP FF AUTO	□ EME	ERGENCY STOP		
				□ No na	ameplate   Sp	ecify lette	ers (			)		
5. Wall Mo	unt Lead-in											
Fitting (	E1/E2)	IECE	x/ATEX/Ex-CCC ce	artified	EC2B-110, M25	210, 310		E	C2B-410, M32	510		
	ut specification		-UL, IECEX/ATEX o		NPT	3/4			NPT	1		
(standa	ard reducer)		110, 210, 310		•		410, 510	)				
			Cable lead-in method	od Ched	ck Specification	Code	Cable lea	ad-in method	Check	Specification		
					M16					M25		
With specification					M20					M32		
					M25 M32					M40 NPT 3/4		
		E1	Reducer		NPT 1/2	E2	Re	educer		NPT 1		
					NPT 3/4					NPT 1 1/4		
					NPT 1					G3/4 (22)		
					G1/2 (16)					G1 (28)	31 (28)	
					G3/4 (22) G1 (28)	* C +b	ood is not	avaiable ar		G1 1/4 (36)	ified	
• Speci	ify wiring diagram	when	wiring is require	4	• Specify whe					IECEx/ATEX cert	inleu.	

IDEC		(	/ )	EC2B	TIIS Certi	ified Model
TO: IDEC	Corporation			1-co	lumn Control Box S	pecification Sheet
	Company:			TEL:		No. of Control Bo
	Contact Perso	on:		FAX:		
Select the red	quired specifications by	checking the checkboxe	es ( 🗸 ), and s	pecify the detai	ils.	
1. Mour	nting method	☐ Wall mount	□ Pole r	nount		
	rol box size  □ EC2B-110  Nameplate	□ EC2B-210	□ EC	2B-310	□ EC2B-410	□ EC2B-510
	① <u>E1</u>	② <u>E</u> 1		① ② ③ E1	② ③ ④ E2	② ③ ④ ⑤ □
□ No	Leger Maxir	rial: Acrylic (53 mm × 12 m nd color: black letter, white mum no. of letters: 19 letter	background	to 2 lines)  1s 2 lines	ot line 	
4. Contr	rol Units					
Pos	sition Control Unit	Part No.		Con	trol Unit Nameplate	
	1)		☐ ON ☐ OFF ON ☐ No namep	□ OFF □ HAND AUT late □ Spe	☐ START ☐ STOP  O ☐ HAND OFF AUTO  cify letters (	☐ EMERGENCY STOP☐ Blank
	2		☐ ON ☐ OFF ON ☐ No namep	□ OFF □ HAND AUT late □ Spe	☐ START ☐ STOP  TO ☐ HAND OFF AUTO  cify letters (	☐ EMERGENCY STOP☐ Blank
(	3)		□ ON □ OFF ON □ No namep		☐ START ☐ STOP  O ☐ HAND OFF AUTO cify letters (	☐ EMERGENCY STOP☐ Blank )
(	4)		□ ON □ OFF ON □ No namep		☐ START ☐ STOP TO ☐ HAND OFF AUTO cify letters (	☐ EMERGENCY STOP☐ Blank )
	5)		☐ ON ☐ OFF ON ☐ No namep	□ OFF □ HAND AUT late □ Spe	☐ START ☐ STOP  O ☐ HAND OFF AUTO  cify letters (	□ EMERGENCY STOP □ Blank )

### 5. Wall Mount Lead-in Fitting (E1/E2) (Specification is not necessary for pole mount)

- G3/4 screw (22) reducer is used for EC2B-110, 210, 310 types.
   G1 screw (28) reducer is used for EC2B-410, 510 types.
- Standard reducer is used if unspecified.

EC2B-110, 210, 310

EU2B-11	C2B-110, 210, 310						
Code	Cable lead-in method	Check	Specification				
	Reducer (metal conduit)		G1/2 (16)				
			G3/4 (22)				
			G1 (28)				
	Flameproof packing cable lead-in fitting		ø6 to ø8				
E1		cable lead-in fitting		ø8 to ø10			
				ø10 to ø12			
				Ø12 to Ø14			
	(cable)		ø14 to ø16				
			ø16 to ø18				
			ø18 to ø20				

EC2B-410, 510						
Code	Cable lead-in method Check Specification					
	Dadwass		G3/4 (22)			
	Reducer (metal conduit)		G1 (28)			
	(motal contain)		G1 1/4 (36)			
			ø12 to ø14			
E2	Flameproof packing cable lead-in fitting		ø14 to ø16			
			ø16 to ø18			
			ø18 to ø20			
	(cable)		ø20 to ø23			
			ø23 to ø26			

The values in () indicate the nominal sizes.

<sup>•</sup> Specify wiring diagram when wiring is required.

# **IDEC CORPORATION**

**Head Office** 

6-64, Nishi-Miyahara-2-Chome, Yodogawa-ku, Osaka 532-0004, Japan

USA IDEC Corporation Tel: +1-408-747-0550 opencontact@idec.com Germany APEM GmbH Tel: +49-40-25 30 54-0 service@eu.idec.com Singapore IDEC Izumi Asia Pte. Ltd. Tel: +65-6746-1155 info@sg.idec.com IDEC Asia (Thailand) Co., Ltd Tel: +66-2-392-9765 Thailand sales@th.idec.com IDEC Controls India Private Limited Tel: +91-80679-35328 info\_india@idec.com India **IDEC Taiwan Corporation** Tel: +886-2-2577-6938 service@tw.idec.com Taiwan

IDEC Izumi (H.K.) Co., Ltd. IDEC (Shanghai) Corporation Beijing Branch

**Hong Kong** 

China

Japan

Guangzhou Branch IDEC Corporation

Tel: +852-2803-8989 Tel: +86-21-6135-1515 Tel: +86-10-6581-6131 Tel: +86-20-8362-2394 Tel: +81-6-6398-2527

www.idec.com

info@hk.idec.com idec@cn.idec.com idec@cn.idec.com idec@cn.idec.com jp\_marketing@idec.com

